

## Rigging

- Tie the boat cover to the dock
- Do not install the rudder until the boat is in the water
- Do not tension the rig until the boat is in the water

## Putting the boats away

- Remove rudder and centerboard bungee before hauling the boat up
- Roll the sails neatly
- Remove hull plugs and scupper plugs
- Remove gooseneck; leave the pin on the mast
- Put the cover on before tying the boat to the cradle
- Run the tie down line over the cover and through the u-bolt using the extra loop for a purchase
-